

C2R Ex Competition - Coach2Rider



User Instructions -

The Coach to Rider C2R Ex Competition rider headsets are provided as a pair.



With one Coach Transmitter/receiver up to 4 rider sets can be added at a later stage when required.

The C2R is designed to be easy to use and set up. We don't think you need to take instructions with you every time you set up for use by the arena..

The user operation of Coach or Rider transmitters/receivers is identical.



Use Step by Step Guide -

1. Turn on the Coach device first

Then turn on all Rider devices.

2. Lithium Ion Batteries and Charging -

The C2R sets are checked in the United Kingdom Prior to despatch. The devices are supplied in a fully charged condition, therefore, when plugged into the supplied charger there will be no red light indication of charging.

If the battery display shows a low capacity, when charging a **red light** will illuminate the display in the top right hand corner. When fully charged the red light will turn off. Please charge the devices in the Power Off position.

Two devices can be charged with the supplied USB UK 240v plug and cables. **NOTE: Do not attempt to charge via the Audio Jack as the connection is different.**

3. Insert the headset into the mic hole.

Make sure the jack is inserted tightly to make a good connection. When new the connection may be tight push well home a few times to make a good first contact.

4. The LCD Display

- (a) Volume - The LCD display will show the volume number on the left hand side. The volume can be set from 0-4. When in Lock mode (After channels have been set) the volume can be adjusted up or down. Be careful not to accidentally turn the volume up or down by accident when using.
- (b) Channel - The LCD display will show the chosen channel on the right hand side. All devices ship in channel 01. Change this channel to a different number when other radio sets are in use at your location. To adjust the channel press the SET key for a few seconds, the word set will display by the signal strength. Then use the volume keys to choose the desired channel on all devices in your network. Finally press LOCK to select and lock the channel. Up to 50 channels can be selected when more than one set is in use locally.

5. The Headsets

We have chosen a headset which is comfortable in most ears, with a stable wind resistant and stable commercial microphone. The headset can be worn by placing it over the ears from the back like glasses but in reverse, or alternatively hung around the coach and riders neck. The microphone can be adjusted so it does not rub on clothing. With most helmets it is possible to insert the headset while wearing the helmet. It can also be removed from behind with out removing the helmet, we recommend the rider practices this before mounting the horse.

NOTE: The earpieces should be wiped with a disinfectant cloth when used by multiple riders. Do not damage the cord on the headsets by wrapping it around the device. DO NOT insert the microphone jack into the charger input.

6. Serial Number

Each Coach and Rider device have a unique serial number on the rear of the unit. Please make a note of the serial number. The number format COMP- 000000 we recommend you register the device with us so we can support you when required. To register e-mail us at info@equestrianX.com with the following details - Name, Address, Purchase Date, Serial Number

NOTES: **Please note the devices are not waterproof**, we recommend keeping them in a dry pocket in extreme weather conditions. Do not leave the units in exposed sunlight when not in use.